

Form 3160-5
(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

JUL 27 8 52 AM '95

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

JALAPENO CORPORATION

3. Address and Telephone No.

PO BOX 1608 ALBUQUERQUE NM 87103

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

330' FNL & 1650' FWL Sec 6-T8S-R32E

5. Lease Designation and Serial No.

NM 0347394

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

South Tomahawk Fed #2

9. API Well No.

30-005-20961

10. Field and Pool, or Exploratory Area

Tomohawk San Andres

11. County or Parish, State

Chaves County NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to plug & abandon well as follows:

1. Set a 35 sx cement plug accross perforations and tag plug. *Top of plug at least 4016'*
2. Cut csg. @ approx. 1700'.
- * 3. Place a 25 sx. cement plug 50' inside stub and another 50' out of casing. *Tag plug.*
4. Place a 25 sx. plug 300-400' tag plug.
- (5. Place 50' Plug.
6. Place 10 sx. plug @ surface.
7. Install plate and dry hole marker.

* This plug needs to extend at least 50' above 8 5/8" casing shoe at 1775'.
If 4 1/2" casing is cut at a different depth a separate 100' cement plug will need to be spotted across the 8 5/8" casing shoe
& the plug will need to be tagged

14. I hereby certify that the foregoing is true and correct

Signed Jeanetta Atkinson

Title Jeanetta Atkinson

(This space for Federal or State office use)

Approved by _____

Conditions of approval, if any: _____

Title _____

APPROVED Date 7/26/95

AUG 8 1995

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See instruction on Reverse Side

RECEIVED

AUG 10 1935

U.S. PUBLIC
OFFICE