Form 3160-5 (June 1990)

N. M. OIL CONS. COmmission **UNITED STATES** P. O. BOX 1980 DEPARTMENT OF THE INTERIORS, NEW MEXICO 88240

BUREAU OF LAND MANAGEMENT

FORM APPROVED Budget Bureau No. 1004-0135

	Expires:	March	31,	199	13
Lease	Designat	ion and	Sei	iai	No
-MK	03473	194			

6, If Indian, Allottee or Tribe Name

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals

		1
SUBMIT	7. If Unit or CA, Agreement Designation	
Type of Well Gas Well Well Other		
2. Name of Operator	8. Well Name and No.	
Jalapeno Corporation	South Tomahawk Federal #2	
3. Address and Telephone No.	9. API Well No. 30. 005. 20961	
PO Box 1608 Albuqu		
4. Location of Well (Footage, Sec., T., R., M., or Survey De	10. Field and Pool, or Exploratory Area	
330' FNL & 1650' FWL	Tomahawk San Andres	
Sec 6-T8S-R32E	11. County or Parish, State	
36C 0-102-K3ZE	Chaves NM	
2. CHECK APPROPRIATE BOY	A TO INDICATE WATER	
STEEK AT HOPHIATE BOX(S	s) TO INDICATE NATURE OF NOTICE,	REPORT, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF A	
Notice of Intent	ma ma	
Trouce of Intern	Abandonment	Change of Plans
Subsequent Report	Recompletion	New Construction
Subsequent Report	Plugging Back	Non-Routine Fracturing
Final Abandonment Notice	Casing Repair	Water Shut-Off
Final Adandonment Notice	Altering Casing	Conversion to Injection
	Other	Dispose Water
		(Note: Report results of multiple completion on Well

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to plug & Abandon well as follows:

- 1. Set a CIBP @ 3950'.
- 2. Dump 35' Cement on CIBP.
- Cut csg. @ approx. 1700'.
- Place a 25 sx. cement plug 50' inside stub and another 50' out of csg. stub and tag plug.
- 5. Place a 25 sx. plug 300-400' Tag plug.
- 6. Place 50' Plug.
- 7. Place 10 sx. plug @ surface.
- 8. Install plate and dry hole marker.

ent or a sency of the Utilitied Saptes any false, fictitious or faudulent statements NANAGEMENT Side
JUL 2 0 1995
Date CHESTER
APPO
cretary 7/19/95



JUL 2 4 1995 UCD HOBBS OFFICE