

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. LG 4803	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator EP Operating Company		8. Farm or Lease Name State "14"
3. Address of Operator 6 Desta Drive, Suite 5250, Midland, TX 79705-5510		9. Well No. 1
4. Location of Well UNIT LETTER <u>H</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>14</u> TOWNSHIP <u>12S</u> RANGE <u>31E</u> NMPM.		10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 4434' GR		12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plans are to plug and abandon the well by setting a 9-5/8" CIBP at 2950'. Dump 35' cement on top of bridge plug. Circulate the hole with 10# brine water mixed 25# per barrel with mud gel. Pump a 100' cement plug from 1400' to 1500'. Lay a 10 sack cement surface plug. Cut off casing head and install the dry hole marker. Clean location for final inspection.

THE OPERATOR MUST BE NOTIFIED 24
HOURS BEFORE THE BEGINNING OF
WORK.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Production Superintendent DATE 12/14/88

ORIGINAL SIGNED BY JERRY SEXTON
APPROVED BY Jerry Sexton DISTRICT SUPERVISOR TITLE _____ DATE DEC 16 1988
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

DEC 15 1988

RECEIVED 1988 YR 050000 JAMMOCD

RECEIVED 1988 YR 050000 HOBBS OFFICE