

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-85

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. LG 2405	
7. Unit Agreement Name	
8. Farm or Lease Name Harris-State	
9. Well No. 1-Y	
10. Field and Pool, or Wildcat W. Tobac-San Andres	
12. County Chaves	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Tom L. Ingram
3. Address of Operator P.O. Box 1757, Roswell, New Mexico 88201
4. Location of Well UNIT LETTER <u>P</u> <u>560</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>26</u> TOWNSHIP <u>8-S</u> RANGE <u>32-E</u> N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) 4444 GR

16.

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>

### SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Plan to P & A as follows:

Cut 5½" csg @ 2270' and recover.  
Set 150' cmt plug @ 2200-2350 (inside & outside 5½" csg stub)  
Set 100' cmt plug @ 1750-1850 (across 8 5/8" csg shoe)  
Set 10 sx cmt plug @ surface.  
Mud laden brine will be placed between all plugs.  
Dry hole marker will be placed when pits are leveled.

Verbal permission for the above obtained from Jerry Sexton (NMOCD) on 2-6-85

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Joseph L. Ingram</u>	TITLE <u>Engineer</u>	DATE <u>2/6/85</u>
ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR		
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		

FEB - 8 1985

RECEIVED

FEB -7 1985

FOR  
LOCAL OFFICE