

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

5a. Indicate Type of Lease

State ☒ Fee ☐

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" FORM C-101 FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Unit Agreement Name
2. Name of Operator Texland Petroleum, Inc.	8. Farm or Lease Name Caprock A State
3. Address of Operator 3402 Texas American Bank Bldg., Fort Worth, TX 76102	9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>N</u> LINE AND <u>660</u> FEET FROM THE <u>E</u> LINE, SECTION <u>33</u> TOWNSHIP <u>10S</u> RANGE <u>31E</u> NMPM.	10. Field and Pool, or Wildcat Wildcat
11. Elevation (Show whether DF, RT, GR, etc.) 4296.4 GL	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposals or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Cut and pull 5 1/2" casing from 2870'.
2. Set cast iron bridge plug at 3924' (50' above top perf.) and cap with 35' of cement.
3. Spot 100' cement from 2750-2850 (1/2 in and 1/2 out of casing cut point). Tag it.
4. Spot 100' cement across 8 5/8" casing shoe at 1368' from 1318' to 1418'. Tag it.
5. Spot 10 sx plug at surface and erect P&A marker.

NOTE: Verbal permission to plug and abandon per this procedure was granted by Jerry Sexton to Mark Jacoby on 2-20-86.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Alan McKinn</u>	TITLE <u>Consultant</u>	DATE <u>2-21-86</u>
APPROVED BY <u>Eddie W. Seay</u> Oil & Gas Inspector	TITLE _____	DATE <u>FEB 25 1986</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

FEB 24 1986

O.C.D.
HOBBS OFFICE