

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

AUG 22 12 50 PM '69

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
--	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>AMERICAN PETROFINA COMPANY OF TEXAS</b>	8. Farm or Lease Name <b>North Caprock Queen Unit #1</b>
3. Address of Operator <b>Box 1311, Big Spring, Texas 79720</b>	9. Well No. <b>Tract 17 - Well No. 5</b>
4. Location of Well UNIT LETTER <b>E</b> , <b>1980</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>6</b> TOWNSHIP <b>13S</b> RANGE <b>32E</b> NMPM.	10. Field and Pool, or Wildcat <b>Caprock Queen Lea</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4380 Gr.</b>	12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approximately 9-22-69

- Spot 50 sx cement plug on bottom (TD 3034) through 2" EUE tubing using mud laden fluid as displacing medium.
- Cut off 5-1/2" casing at 1730', spot 25 sx cement plug at 1730' (5-1/2" casing stub) and pull 5-1/2" casing.
- Spot 25 sx cement plug at 301' (Bottom of 8-5/8")
- Place 10 sx cement plug in top of 8-5/8" casing and set 4-1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cliff Chapman TITLE Petroleum Engineer DATE August 21, 1969  
APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT DATE AUG 25 1969  
CONDITIONS OF APPROVAL, IF ANY: