

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name No. 1	
No. Caprock Queen Unit	
8. Farm or Lease Name	
No. Caprock Queen Unit	
9. Well No.	
Tract 18, Well No. 2	
10. Field and Pool, or Wildcat	
Caprock Queen (Lea)	
12. County	
Lea	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Injection Well
2. Name of Operator Thunderbird Oil Corporation
3. Address of Operator P. O. Box 1778, Midland, Texas 79701
4. Location of Well UNIT LETTER B, 654 FEET FROM THE North LINE AND 1982 FEET FROM THE East LINE, SECTION 6 TOWNSHIP 13-S RANGE 32-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4385' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

10" @ 282' w/150 sx.  
7" @ 3026' w/600 sx.  
5-1/2" Liner @ 2871-3070'

1. Displace hole with 2500# per 100 bbls. salt base mud.
2. Set CIBP at approximately 2800'.
3. Set 35' cement plug (7 sx.) on top of CIBP.
4. Cut off and pull 7" casing at approximately 1000'.
5. Spot 35 sx. cement plug in-and-out of 7" casing stub.
6. Spot 35 sx. cement plug in-and-out of 10" casing stub.
7. Spot 10 sx. cement plug at surface and erect 4 1/2" regulation dry hole marker.
8. Clean up location for NMOCC inspection and approval.

100' plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Harry F. Schuman</u>	TITLE <u>President</u>	DATE <u>Feb. 25, 1975</u>
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY: _____		

RECEIVED

APR 1 1975

U.S. CONSTITUTION COMMISSION  
WASHINGTON, D.C.