

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-01168
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-2114
7. Lease Name or Unit Agreement Name State "H"
8. Well No. #4
9. Pool name or Wildcat Saunders Permo Penn

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Charles B. Gillespie, Jr.	
3. Address of Operator P.O. Box 8 Midland, Texas 79702	
4. Well Location Unit Letter <u>O</u> : <u>660</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>28</u> Township <u>14-S</u> Range <u>33-E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4219 DF	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

In 1986 a Cibp was set and capped at 9750'.

1. Spot 100' plug @ 6500'.
2. Spot 100' plug @ 8-5/8" shoe @ 4150'.
3. Spot 100' plug @ 5-1/2" liner top @ 3954'.
4. Spot 100' plug @ 13-3/8" shoe @ 320'.
5. Put 15 SX plug at surface.
6. Weld 4" dry hole marker.

plug & set 100' plug @ top of salt 1000

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Kevin Widner TITLE Production Manager DATE 09/15/93
TYPE OR PRINT NAME Kevin Widner TELEPHONE NO. (915) 683-1765

(This space for State Use)

Orig. Signed by
Paul Kautz
Geologist

APPROVED BY _____ TITLE _____ DATE SEP 17 1993

CONDITIONS OF APPROVAL, IF ANY:

THIS NOTICE MUST BE NOTIFIED 24 HOURS PRIOR TO BEGINNING OF PLUGGING OPERATION FOR THE C-103