

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

OCT 13 8 57 AM '67

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER: DEPLETED	7. Unit Agreement Name
2. Name of Operator PAN AMERICAN PETROLEUM CORPORATION	8. Farm or Lease Name WINGERD
3. Address of Operator BOX 68, HOBBS, N. M. 88240	9. Well No. 3
4. Location of Well UNIT LETTER A 660 FEET FROM THE NORTH LINE AND 660 FEET FROM THE EAST LINE, SECTION 24 TOWNSHIP 12-S RANGE 37-E NMPM.	10. Field and Pool, or Wildcat GLADIOLA WOLF CAMP
15. Elevation (Show whether DF, RT, GR, etc.) 3877 G.L.	12. County LEA

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1703.

*Zone depleted. No workover or recompletion possibilities.
Proposed to P&A as follows:*

1. Spot 30 sd cement plug (to cover perfs 9607-13) from 9700-9550'.
2. Cut & pull 7" csq from approx 5500' & Spot 25 sd In & Out of Stub.
3. 20 sd plug In & Out of 9 7/8" csq @ 4500'.
4. Cut & pull 9 7/8" csq from approx 1500' Spot 25 sd In & Out of Stub.
5. 20 sd In & Out of 13 7/8" CSA 334'.
6. 10 sd plug @ surface & erect P&A Marker.
7. Make final cleanup and restore ground to contour.

TD-4820 7" CSA. 4817 (TCMT 8510)
PAD-9745 9 7/8" CSA 4500' (TCMT 1720)
Perfs. 9607-9618 13 7/8" CSA 334' (circ)

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____ TITLE AREA SUPERINTENDENT DATE 10-9-67

012-NMOC-11

APPROVED BY
1- SUSP
CONDITIONS OF APPROVAL, IF ANY:
1- RRY

TITLE _____ DATE _____