

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Tom L. Ingram		8. Farm or Lease Name Craig
3. Address of Operator POB 1757, Roswell, New Mexico 88201		9. Well No. 1
4. Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>27</u> TOWNSHIP <u>12S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat SW Gladiola-Penn
15. Elevation (Show whether DF, RT, GR, etc.) 3906 KB		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Confirming telephone conversation, plan to P & A as follows:

Set cast iron bridge plug @ 10,800 with 50 sx. plug on top.
Cut 5 1/2 csg. @ free point (approx. 5500') and pull.
Put 50 sx. cement plug in/out of 5 1/2 stub.
Put 50 sx. cement plug in/out of base 8 5/8" csg. @ 4471.
Cut 8 5/8" csg. @ free point (approx. 1200') and pull.
Put 50 sx. cement plug in/out of 8 5/8" stub.
Put 50 sx. cement plug in/out of base 13 3/8 @ 337.
Put 10 sx. cement plug @ surface with marker.
Clean location.
Mud laden fluid to be used between plugs.

THIS NOTICE OF INTENTION TO PLUG BACK TO A DIFFERENT RESERVOIR OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Tom L. Ingram</u>	TITLE <u>Operator</u>	DATE <u>Sept. 4, 1974</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>Supervisor</u>	DATE <u></u>
CONDITIONS OF APPROVAL, IF ANY:		