

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
E-1027

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator TEXACO Inc.	8. Farm or Lease Name New Mexico "CZ" State
3. Address of Operator P. O. Box 728 - Hobbs, New Mexico 88240	9. Well No. 3
4. Location of Well UNIT LETTER <u>B</u> , <u>710</u> FEET FROM THE <u>North</u> LINE AND <u>2030</u> FEET FROM THE <u>East</u> LINE, SECTION <u>14</u> TOWNSHIP <u>12-S</u> RANGE <u>34-E</u> NMPM.	10. Field and Pool, or Wildcat Ranger Lake (Penn)
15. Elevation (Show whether DF, RT, CR, etc.) 4167' (D.F.)	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>	PLUG AND ABANDONMENT	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>		
OTHER	<input type="checkbox"/>		

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TEXACO proposes to do the following work on subject well:

1. Pull hydraulic pumping equipment and mud up hole.
2. Spot 40 Sx cement plug from 10,003' to 9,903'.
3. Cut off 4-1/2" O.D. casing @ approx. 4,200' and pull.
4. Spot 25 Sx. cement plug 50' below and 50' above cut off.
5. Spot 10 Sx. cement plug @ surface.
6. Set 4" dry hole marker extending 4' above ground level, clean location, and abandon.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Assistant District Superintendent DATE October 15, 1969

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: