

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator Tom L. Ingram		8. Farm or Lease Name Craig "A"	
3. Address of Operator POB 1757, Roswell, New Mexico 88201		9. Well No. 1	
4. Location of Well UNIT LETTER <u>H</u> <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM THE <u>East</u> LINE, SECTION <u>27</u> TOWNSHIP <u>12-S</u> RANGE <u>37-E</u> NMPM.		10. Field and Pool, or Wildcat Gladiola-Wolfcamp	
15. Elevation (Show whether DF, RT, GR, etc.) 3890.7 Ground		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1705.

Open perforations are from 9532-9684' in Wolfcamp pool. Will set CIBP @ 9000' & spot 5 sx. cement plug on top. Will spot cement plugs as follows:

1. 30 sx. cement plug in & out 5 $\frac{1}{2}$ " csg. stub (est. @ 5000')
2. 50 sx. cement plug in & out 8-5/8" csg. shoe @ 4500'
3. 50 sx. cement plug in & out 8-5/8" csg. stub (est. @ 1500')
4. 75 sx. cement plug in & out 13-3/8" csg. shoe @ 350'
5. 10 sx. cement plug in top surface casing.

Mud laden fluid will be left in csg. & open hole.

THE COMMISSION MUST BE NOTIFIED
24 HOURS PRIOR TO ~~SETTING~~
Setting bottom plug.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Tom L. Ingram</u>	TITLE <u>Operator</u>	DATE <u>May 25, 1973</u>
APPROVED BY <u>John W. Remy</u>	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		