

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

RECEIVED

MAR 23 1970

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5b. Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name DYE	
9. Well No. 1	
10. Field and Pool, or Wildcat UNDEVELOPED	
12. County LEA	

SUNDY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- DRY HOLE
2. Name of Operator JACK L. MCCLELLAN
3. Address of Operator P. O. Box 848, ROSWELL, NEW MEXICO 88201
4. Location of Well UNIT LETTER P 660 FEET FROM THE SOUTH LINE AND 660 FEET FROM THE EAST LINE, SECTION 28 TOWNSHIP 13S RANGE 34E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4145' G. L.

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>
OTHER <input type="checkbox"/>

PLUG AND ABANDON <input checked="" type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>
OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>

ALTERING CASING <input type="checkbox"/>
PLUG AND ABANDONMENT <input type="checkbox"/>
OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

PROPOSE TO PLUG AND ABANDON THE ABOVE TEST AS FOLLOWS:

WITH WELL FULL OF DRILLING MUD, SET 50 SACK CEMENT PLUG AT 9650' OR DEEPEST DEPTH POSSIBLE. PLACE 25 SACK PLUG IN AND OUT OF 4 1/2" CASING CUT OFF. IF GLORIETA ZONE IS EXPOSED, WILL PLACE 25 SACK PLUG AT TOP OF SECTION. PLACE 25 SACKS IN AND OUT OF STUB OF 8-5/8" CASING, 25 SACK PLUG AT TOP OF SALT, 25 SACK AT BOTTOM OF 13-3/8" SURFACE CASING, 10 SACKS AT SURFACE, INSTALL DRY HOLE MARKER AND CLEAN LOCATION.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>J. L. McClellan</u>	TITLE <u>OPERATOR</u>	DATE <u>3-20-70</u>
APPROVED BY <u>[Signature]</u>	TITLE <u></u>	DATE <u></u>
CONDITIONS OF APPROVAL, IF ANY:		