

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

HC OFFICE O.C.C.
NEW MEXICO CONSERVATION COMMISSION
MAY 12 1969

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.
- - -

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole	7. Unit Agreement Name - - -
2. Name of Operator Coastal States Gas Producing Company	8. Farm or Lease Name Chambers
3. Address of Operator P. O. Box 235, Midland, Texas 79701	9. Well No. 2
4. Location of Well UNIT LETTER <u>D</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>29</u> TOWNSHIP <u>13S</u> RANGE <u>33E</u> NMPM.	10. Field and Pool, or Wildcat Undes. No. Baum
15. Elevation (Show whether DF, RT, GR, etc.) 4264.8' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☒

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Chambers No. 2 was spudded 3-2-69; set 13-3/8 casing @392' and set 8-5/8" casing @4060'. Well drilled to TD 10,000'. Ran Dual Injection Laterolog, Sidewall Neutron Porosity and Micrologs - result showed well to be dry and non-productive.

Well was temporarily abandoned as follows:

1. 35 sxs cement plug 9807-9697
2. 35 sxs cement plug 7520-7410
3. 35 sxs cement plug 5389-5279
4. 50 sxs cement plug in and out of 8-5/8 shoe 4136-3980.

Well will be plugged and abandoned as follows:

1. 25 sxs cement plug in top of 8-5/8 stub
2. 25 sxs cement plug top of salt
3. 25 sxs cement plug in and out of 13-3/8 shoe
4. 10 sxs cement plug surface
5. Weld steel plate on top of 13-3/8" and install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Joe P. Howard TITLE Division Production Manager DATE May 9, 1969
APPROVED BY [Signature] TITLE [Signature] DATE [Signature]
CONDITIONS OF APPROVAL, IF ANY: