

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-622
7. Unit Agreement Name
8. Farm or Lease Name Tenneco B-State
9. Well No. 1
10. Field and Pool, or Willcat Cerca, Upper Penn
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Amini Oil Corporation
3. Address of Operator 400 Wall Towers West Midland, Texas 79701
4. Location of Well UNIT LETTER F, 2086 FEET FROM THE North LINE AND 2086 FEET FROM THE West LINE, SECTION 8 TOWNSHIP 14-S RANGE 34-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4147 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set a 30 sx. cement plug at 10,400' (Perforations from 10,426' to 10,431 1/2')
- Fill hole with mud laden fluid.
- Cut and pull 5 1/2" casing.
- Set a 30 sx. cement plug at top of 5-1/2" casing stub.
- Set a 30 sx. cement plug at 4350' (8-5/8" casing set at 4328')
- Cut and pull 8-5/8" casing.
- Set a 30 sx. cement plug at top of 8-5/8" casing stub.
- Set a 30 sx. cement plug at 380' (12-3/4" casing set at 368')
- Place 10 sx. cement in top of surface.
- Set marker and clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Ewen Patton</u>	TITLE <u>Agent</u>	DATE <u>Nov. 30, 1970</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT</u>	DATE <u>DEC 2 1970</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

1970

OIL CONSERVATION COMM.
HOUSTON, N. H.