

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.  
30-025-24531

5. Indicate Type of Lease  
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.  
K-3662

7. Lease Name or Unit Agreement Name

Union State

8. Well No.  
1

9. Pool name or Wildcat  
Morton Permo Penn, North

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator  
ELK OIL COMPANY

3. Address of Operator  
Post Office Box 310, Roswell, New Mexico 88202-0310

4. Well Location  
Unit Letter N : 1650 Feet From The West Line and 330 Feet From The South Line  
Section 25 Township 14 South Range 34 East NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
4076.5 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WORK ☐ ALTERING CASING ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
PULL OR ALTER CASING ☐ CASING TEST AND CEMENT JOB ☐  
OTHER: ☐ OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. Intend to plug and abandon as follows:

- (1) Set Cast Iron Bridge Plug at 9700' with 35' of cement on top.
- (2) Cut 4½ casing at 8000' and recover.
- (3) Set 100' plug in and out of 4½ casing stub at 8000'.
- (4) Set 100' plug at 6000'.
- (5) Set 100' plug in and out of 8 5/8 shoe at 4500'.
- (6) Cut 8 5/8 casing at 1200' and recover.
- (7) Set 100' plug in and out 8 5/8 casing stub.
- (8) 100' plug at surface.
- (9) Install 4'X4' dry hole marker.

100' PLUG 50' in & 50' out of 13 3/8  
Clean and level location.  
Plug mud between all plugs.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Joseph J. Kelly TITLE President DATE 9/27/91  
TYPE OR PRINT NAME Joseph J. Kelly TELEPHONE NO. 505-623-3190

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24  
HOURS PRIOR TO THE BEGINNING OF  
PLUGGING OPERATIONS FOR THE C-103  
TO BE APPROVED.