

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Red Branch Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. <u>30-025-28930</u>
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LG-2358
7. Lease Name or Unit Agreement Name Sunburst State
8. Well No. 1
9. Pool Name or Wildcat Wildcat <u>Baum Upper Penn</u>

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>	
2. Name of Operator Manzano Oil Corporation 505/623-1996	
3. Address of Operator P.O. Box 2107/Roswell, NM 88202-2107	
4. Well Location Unit Letter <u>N</u> : <u>660</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>11</u> Township <u>14 South</u> Range <u>32 East</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4299' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Will set CIBP or 100' of cement 100' above present perforations of 8946-68' overall. Tag plug. Cut off and recover as much 5-1/2" casing as possible. Place 100' cement plug at 5-1/2" casing stub. Tag plug. Place 100' cement plug @ 5435'. Tag plug. Place 100' cement plug @ 4020' across 8-5/8" casing shoe. Tag plug. Place 100' cement at top of salt at 1680'. Place 10 sks surface plug.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE William Ramsey TITLE Production Analyst DATE 11/5/92
TYPE OR PRINT NAME TELEPHONE NO.

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

NOV 09 '92

RECEIVED
NOV 06 1952
ORD HOUSE OFFICE