

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>K-4838</b>

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>Amerada Petroleum Corporation</b>	8. Farm or Lease Name <b>State NH "A"</b>
3. Address of Operator <b>P. O. Box 668 - Hobbs, New Mexico</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>F</b> , <b>1980</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>36</b> TOWNSHIP <b>6S</b> RANGE <b>34E</b> NMPM.	10. Field and Pool, or Wildcat <b>Wildcat</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4295 DF</b>	12. County <b>Roosevelt</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to spot 25 sack cement plug at PBD 4402' to cover perforations 4271' to 4318'.  
Cut 4-1/2" casing at approximately 3400' and spot 25 sack cement plug from 3400' to  
cover top of San Andres at 3365'. Spot 25 sack cement plug at top of salt (approximately  
2100') and 25 sack cement plug in and out of 8-5/8" casing set at 421' and a 10 sack  
cement plug in top of 8-5/8" casing with dry hole marker.  
A 9.2# material will be used to plug well.

*The following additional plug will be necessary:  
25 SRS plug at base of salt.*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Lo Debb* TITLE District Superintendent DATE February 17, 1969

APPROVED BY *John W. Ruyman* TITLE  DATE

CONDITIONS OF APPROVAL, IF ANY:

*Note Above*