

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease

State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- DRY	7. Unit Agreement Name
2. Name of Operator SUNDANCE OIL COMPANY	8. Farm or Lease Name Newman
3. Address of Operator Suite 510, 1776 Lincoln St., Denver, CO 80203	9. Well No. 1
4. Location of Well UNIT LETTER C, 660 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 35 TOWNSHIP 6 South RANGE 32 East N10PM.	10. Field and Pool, or Wildcat Wildcat, San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 4446' GL	12. County Roosevelt

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Fill the hole with heavy drilling mud. Attempt to shoot off 4½" production casing at 3300'. Place 50 sx cement plug on top of 4½" casing stub (where shot off). Pull 4½" casing to 1900'. Place 35 sx cement plug in and out of base of surface casing. Recover remaining 4½" casing. Put 10 sx plug in top of surface casing and install proper well marker. Clean up, rip drilling pad to a minimum of 12" in depth and re-seed in accordance with the BLM stipulations. Will leave access road intact.

100' plug above surf.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Richard O. Dimit TITLE Vice President, Production DATE June 5, 1980

APPROVED BY [Signature] TITLE DATE JUN 3 1980

CONDITIONS OF APPROVAL: NONE