

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-77

1a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
Name of Operator Amoco Production Company		8. Field or Lease Name Killion
Address of Operator P. O. Box 68 Hobbs, NM 88240		9. Well No. 1
Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>19</u> TOWNSHIP <u>5-S</u> RANGE <u>33-E</u> NMPM.		10. Field and Pool, or Wildcat South Peterson Fusselman
15. Elevation (Show whether DF, RT, GR, etc.) 4413.1' GL		12. County Roosevelt

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to P X A well per the following:

Pull tubing and packer. Set a 75-sack Class H cement plug from 7190-7790'. Spot a 30-sack Class H cement plug from 4300'-4500'. Run free point log to determine free point of 5-1/2" casing. Cut casing one joint above free point and pull casing out of hole. Spot a 65-sack Class H cement plug 1925'-2075' in and out of 8-5/8" casing shoe. Spot a 10-sack (20') surface plug and erect P X A marker. Restore location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS BEFORE THE BEGINNING OF PROPOSED OPERATIONS FOR THE C-103 TO BE APPROVED.

0+4-NMOCD, H 1-Hou 1-Susp 1-LBG 1-W. Stafford, Hou

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Benton Green TITLE Assist. Admin. Analyst DATE 6-12-81

APPROVED BY [Signature] TITLE [Signature] DATE JUN 16 1981

CONDITIONS OF APPROVAL, IF ANY: