

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. #) 30-041-20601
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Lease Name or Unit Agreement Name Crume #1
2. Name of Operator Bledsoe Partners, Inc. → Petro Corp	8. Well No. 1
3. Address of Operator 3705 W Memorial Road #1401 Oklahoma City, Ok 73134	9. Pool name or Wildcat Peterson Penn Assoc South
4. Well Location Unit Letter C : 660 Feet From The north Line and 1980 Feet From The west Line Section 13 Township 6SA Range 33E NMPM Roosevelt County	

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
4372.5 GL

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBB @ 6040 w/ 2 sk of cement on top
2. Circ hole w/ mud.
3. Cut & pull 4 1/2 CST
4. Spot 100' cement plug at cut off pt. 50 in and out of hole
5. Spot 100' cement plug at 4500'
6. Spot 100' cement plug at 3350' (50' below 8 5/8)
7. Spot 50' cement plug to surface
8. Cut and cap surf csg, weld on dry hole marker, clean location

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PRODUCTION OPERATIONS FOR THE C-103
TO BE PRODUCED

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Mike Conner TITLE Production Supervisor DATE 10/26/95
TYPE OR PRINT NAME Mike Conner (405) 748-5050 TELEPHONE NO.

(This space for State Use)

ORIGINAL SIGNED BY MARY SEXTON

OCT 31 1995

APPROVED BY MARK L. FLETCHER TITLE STATE ENGINEER DATE 10/26/95

CONDITIONS OF APPROVAL, IF ANY:

