

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

AUG 22 12 00 PM '69

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>E-5667</b>
7. Unit Agreement Name
8. Farm or Lease Name <b>State "B"</b>
9. Well No. <b>2</b>
10. Field and Pool, or Wildcat <b>Anderson Ranch Wolf., No.</b>
12. County <b>Lea</b>

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator <b>Union Oil Company of California</b>
3. Address of Operator <b>P. O. Box 671; Midland, Texas 79701</b>
4. Location of Well UNIT LETTER <b>A</b> , <b>990</b> FEET FROM THE <b>North</b> LINE AND <b>990</b> FEET FROM THE <b>East</b> LINE, SECTION <b>33</b> TOWNSHIP <b>15-S</b> RANGE <b>32-E</b> N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) <b>4292' GR</b>

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Set bridge plug at 9900' and cap with 20' cement.

Cut and pull 4-1/2" casing from free point.

Spot cement plugs as follows:

40 sx. - in and out of 4-1/2" casing stub,

35 sx. - top of Glorieta - 5700',

50 sx. - 4150' - 4050'.

cut and pull 8-5/8" casing from free point.

35 sx. - in and out of 8-5/8" casing stub,

50 sx. - 650' - 500',

10 sx. - Surface - 30'.

Weld on cap, install dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED: R.G. Ladd, Jr. TITLE: District Drilling Supt. DATE: August 21, 1969

APPROVED BY: [Signature] TITLE: [Signature] DATE: AUG 25 1969

CONDITIONS OF APPROVAL, IF ANY: