

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE\*  
(Other instructions on re-verse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 0969

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☐ GAS WELL ☐ OTHER ☒ Injection Well

2. NAME OF OPERATOR

Aztec Oil & Gas Company

3. ADDRESS OF OPERATOR

P.O. Box 837, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)

At surface Unit Letter B, 660'/NL 1980'/EL, Sec. 31-16S-32E

7. UNIT AGREEMENT NAME

Robinson Unit

8. FARM OR LEASE NAME

Robinson Unit Tr. 2-31

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Malj. Grayb. S.A.

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

31-16S-32E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4149 GR

12. COUNTY OR PARISH

Lea

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF (RECOMPLETION OR)

SUBSEQUENT WORKS OF:

TEST WATER SHUT-OFF ☐

PULL OR ALTER CASING ☐

WATER SHUT-OFF ☐

REPAIRING WELL ☐

FRACTURE TREAT ☐

MULTIPLE COMPLETION ☐

FRACTURE TREATMENT ☐

ALTERING CASING ☐

SHOOT OR ACIDIZE ☐

ABANDON\* ☒

SHOOTING OR ACIDIZING ☐

ABANDONMENT\* ☐

REPAIR WELL ☐

CHANGE PLANS ☐

(Other) ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

It is proposed to plug and abandon in the following manner: No casing will be pulled;

1. Set 100' cement plug at top perforations at 3848-4054' (Overall)
2. Fill casing with mud.
3. Set 100' cement plug at 990' (Top Salt)
4. Set 10' plug at surface with marker.
5. Clear, level and clean location.

Note: It may be necessary to set bridge plug above perfs. w/35' cement plug instead of 100' cement plug.

AMENDMENT: 1. Set additional 25 sack plug inside 4 1/2" casing in interval 2300-2500 feet.  
2. If no 4 1/2" casing is pulled, perforate at 900 feet and place 25 sacks

cement through perforations and leave 25 sack plug inside casing in interval 700-900 feet.

SIGNED Arthur R. Brown TITLE District Superintendant DATE 10/7/74

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side

