

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B 3610	
7. Unit Agreement Name	
8. Farm or Lease Name Phillips Lexco State	
9. Well No. Phillips 4	
10. Field and Pool, or Wildcat Maljamar	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Ryder Scott Management Company	
3. Address of Operator 922 - 8th Street, Wichita Falls, Texas 76301	
4. Location of Well UNIT LETTER M, 660 FEET FROM THE South LINE AND 450 FEET FROM THE West LINE, SECTION 2 TOWNSHIP 17 RANGE 32 NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.) 4191 KB	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work to start on approval (approximately 3-18-68)

We will pull all retrievable tubing and rods, install cast iron bridge plug above top perforations, fill casing and hole with mud-laden fluid, pull casing & install 10 sack cement plug in surface pipe. Erect marker & clean up surface.

1. Cap bridge plug w/ cement
2. 25 SXS @ stub
3. 25 SXS @ top of salt, if exposed
4. 25 SXS across surface casing shoe
5. 10 SXS @ surface
Meadow

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____ TITLE Asst. Prod. Supt. DATE March 11, 1968

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

Joe L. Hamey