

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
		5. State Oil & Gas Lease No. B 3610
1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Ryder Scott Management Company		8. Farm or Lease Name Phillips Lexco State
3. Address of Operator 922 - 8th Street, Wichita Falls, Texas 76301		9. Well No. 1
4. Location of Well UNIT LETTER <u>O</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>2</u> TOWNSHIP <u>18</u> RANGE <u>32</u> NMPM.		10. Field and Pool, or Wildcat Maljamar
15. Elevation (Show whether DF, RT, GR, etc.) 4264 GL		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work to start on approval (approximately 3-18-68)

We will pull all retrievable tubing & rods, install cast iron bridge plug above top perforations, fill casing and hole with mud-laden fluid, pull casing & install 10 sack cement plug in surface pipe. Erect marker & clean up surface.

1. Cap bridge plug w cement
2. 25 SXS @ casing stub
3. 25 SXS @ Top of salt, if exposed,
4. 25 SXS across sur face ~~at~~ casing shoe
5. 10 SXS @ sur face

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mac C. Howard TITLE Asst. Prod. Supt. DATE March 11, 1968

APPROVED BY Jol Ramsey TITLE Supervisor District 1 DATE

CONDITIONS OF APPROVAL IF ANY