Form 3160-5 (November 1983) (Formerly 9-331)

UNITE STATES DEPARTMENT OF THE INTERIOR

SUBMIT IN TRIPLIC..... * (Other Instructions on

Budget Bureau No. 1004-0135 Expires August 31, 1985

reverse side) **BUREAU OF LAND MANAGEMENT** 5. LEASE DESIGNATION AND SERIAL NO. N.M. Oil Cons_MDivision SUNDRY NOTICES AND REPORTS ON WELLS 1625 N. Freit D'ALLOTTEE OR TRIBE NAME (Do not use this form for proposals to drill or to deepen or plug back to a different reso Hobbs, NM 88240 Use "APPLICATION FOR PERMIT - " for such proposals.) 1. 7. UNIT AGREEMENT NAME OTHER OIL GAS Maljamar Grayburg WELL WELL P & A 2. NAME OF OPERATOR 8. API No. The Wiser Oil Company 30-025-00461 ADDRESS OF OPERATOR 9. WELL NO. P.O. Box 2568 Hobbs, New Mexico 88241 23 LOCATION OF WELL (Report location clearly and in accordance with any State requirements. 10. FIELD AND POOL, OR WILDCAT See also space 17 below.) Maljamar Grayburg San Andres At surface 11. SEC., T., R., M., OR BLK. AND **SURVEY OR AREA** 2310' FSL & 330' FWL Sec. 4-T17S-R32E Unit L 12. COUNTY OR PARISH 14. PERMIT NO 15. ELEVATIONS (Show whether DF, RT, GR, etc.) 13. STATE 4118' GL Lea County N.M. Check Appropriate Box to indicate Nature of Notice, Report, or Other Data 16. NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: **TEST WATER SHUT OFF** PULL OR ALTER CASING WATER SHUT-OFF REPAIRING WELL FRACTURE TREAT MULTIPLE COMPLETE FRACTURE TREATMENT ALTERING CASING SHOOT OR ACIDIZE SHOOTING OR ACIDIZING ABANDON* ABANDONMENT * **REPAIR WELL CHANGE PLANS** (Other) (Note: Report results of multiple completion on Well (Other) Completion or Recompletion Report and Log form.) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) Wiser Oil requests approval to Plug and Abandon the well by the procedure listed below. MIRU unit. Drill cement and retainers from surface down to 3780'. Circulate abandonment mud. Set 25 sks. cement plug (2) 2160'. Tag cement plug. 3. Set 25 sks. cement plug @ 700'. Tag cement plug. 5. Perforate casing @ 370' and circulate cement to surface. Set 25 sks. cement plug from 50' to surface. 6. Install dry hole marker. Clean location. 18. I hereby certify that the foregoing is true and correct. TITLE Completion Department DATE December 12, 2000 **SIGNED** (This space for Federal or State office use)

e Instruction On Reverse Side

it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

PETROLEUM ENGINEER

DATE

APPROVE (QRIG. SGD.) [IAVID R. GLASS

CONDITIONS OF APPROVAL, IF ANY:

GWW

2000 DEC 15 P 3: 45

4.