

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No. 723	
7. Unit Agreement Name	
8. Farm or Lease Name Trimble A	
9. Well No. 2	
10. Field and Pool, or Wildcat Maljamar	
12. County Lea	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Ryder Scott Management Company
3. Address of Operator 922 - 8th Street, Wichita Falls, Texas 76301	4. Location of Well UNIT LETTER <u>G</u> 1980 FEET FROM THE <u>North</u> LINE AND 1980 FEET FROM THE <u>East</u> LINE, SECTION <u>11</u> TOWNSHIP <u>17</u> RANGE <u>32</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4144 G. L.	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work to start approximately 3-18-68 (on approval)

We will pull all retrievable tubing & rods, install cast iron bridge plug above top perforations, fill casing and hole with mud-laden fluid, pull casing & install 10 sack cement plug in surface pipe. Erect marker & clean up surface.

1. Cap bridge plug w/ cement
2. 25 sacks @ casing stub
3. 25 sacks @ top of well, if exposed
4. 25 sacks across surface casing shoe
5. 10 sacks @ surface.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Prod. Supt. DATE March 11, 1968

APPROVED BY [Signature] TITLE [Signature] DATE [Signature]

CONDITIONS OF APPROVAL, IF ANY [Signature]