

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 7-871
7. Unit Agreement Name -
6. Farm or Lease Name M 10' St. NCT-3
9. Well No. 22
10. Field and Pool, or Wildcat El Jamar Grayburg San Andres
12. County Lea

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO RE-OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator TEXACO Inc.
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER F, 1980' FEET FROM THE North LINE AND 1982' FEET FROM THE West LINE, SECTION 12, TOWNSHIP 17-S, RANGE 32-E, NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4240' (DF)

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP at 4070' with 35' (3 sx) cement on top.
2. Load hole with mud (25 sx gel per 100 bbls. water).
3. Run free point. Cut and pull 4 1/2" casing.
4. Spot 100' (10 sx) cement plug at top of Queen at 3550'.
5. Spot 100' (15 sx) cement plug at 4 1/2" casing stub.
6. Spot 100' (20 sx) cement plug at base of salt at 2500'.
7. Spot 100' (20 sx) cement plug at top of salt at 1380'.
8. Spot 30' (8 sx) cement plug at surface..
9. Install marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Asst. Dist. Surt.</u>	DATE <u>7-11-77</u>
APPROVED BY <u>[Signature]</u>	TITLE <u></u>	DATE <u>7-11-77</u>
CONDITIONS OF APPROVAL, IF ANY: <u>Expires 1/13/78</u>		

101-2471

JUL 25 1971  
 OIL CONSERVATION COMMISSION  
 HOBBBS, E. M.