

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name <b>Maljamar (Grayburg)</b>
2. Name of Operator <b>Chevron U. S. A. Inc.</b>	8. Farm or Lease Name <b>Maljamar Unit</b>
3. Address of Operator <b>P. O. Box 1660, Midland, Texas 79702</b>	9. Well No. <b>72</b>
4. Location of Well UNIT LETTER <b>E</b> <b>2310</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>14</b> TOWNSHIP <b>17-South</b> RANGE <b>32-East</b> N.M.P.M.	10. Field and Pool, or Wildcat <b>Maljamar (Grayburg-SA)</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>DF 4066</b>	12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒  
TEMPORARILY ABANDON ☐  
FULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☐  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull tubing and rods.
2. Clean wellbore and existing perforations free of scale using Hydraulic cleaning system.
3. Perforate following intervals: 3787-3795, 3818-3833, 3837-3858, 3924-3929, 3937-3975.
4. Acidize the above perforations with 9000 gallons 15% HCL acid and treat with scale inhibitor.
5. Run in hole with tubing, then rods and pump. Put back on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* **B. E. Schubarth** TITLE **Petroleum Engineer** DATE **12-6-82**

ORIGINAL SIGNED BY

APPROVED BY **JERRY SEXTON**

CONDITIONS OF APPROVAL, IF ANY, **DISTRICT 1 SUPR.**

TITLE

DATE **DEC 8 1982**

RECEIVED

DEC 7 1982

G.C.O.  
HOBBS OFFICE