

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. <u>30-025-0058700</u>
5. Indicate Type of Lease <u>Federal</u> STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. <u>LC-0294058</u>
7. Lease Name or Unit Agreement Name <u>MCA Unit Bty 1</u>
8. Well No. <u>1</u>
9. Pool name or Wildcat <u>Maljamar G-5A</u>

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <u>Injection</u>	
2. Name of Operator <u>Conoco, Inc.</u>	
3. Address of Operator <u>PO Box 4100 - Hobbs, NM 88240</u>	
4. Well Location Unit Letter <u>B</u> : <u>690</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>17</u> Township <u>17S</u> Range <u>32E</u> NMPM <u>Lea</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Backflow well. MIREU, ND Wellhead and NU BCP.
2. Release Otis Lockset PKr.
3. Abandon Grayburg and S.A. perms. Set cmt. retainer @ 3580'. Pump 75 sx cmt thru retainer. Sting out and dump 25 Sx on top of retainer from 3370-3580' Displace cmt & circ. hole w/ mud.
4. Spot a 25 sx cement plug from 210' to surface.
5. Cut casing strings 3' below ground level. Erect P & A marker

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE W.W. Baker TITLE Administrative Supervisor DATE Aug. 18, 1989

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for **ORIGINAL SIGNED BY JERRY SEXTON**
DISTRICT I SUPERVISOR)

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED

AUG 24 1989