

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instruction
reverse side)

1. This approval is for
Budget Bureau No. 1004-0115
Expires August 31, 1985

2. LEASE DESIGNATION AND SERIAL NO.

LC-029405B

3. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER Injection

2. NAME OF OPERATOR

Conoco Inc.

3. ADDRESS OF OPERATOR

P.O. Box 460 - Hobbs, NM 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

Unit Letter B

14. PERMIT NO.

30-025-0058700

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

7. UNIT AGREEMENT NAME

MCA Unit

8. FARM OR LEASE NAME

MCA Unit

9. WELL NO.

No. 1

10. FIELD AND POOL, OR WILDCAT

Maljamar G-SA

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 17, T17S, R32E

12. COUNTY OR PARISH 13. STATE

Lea

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETION ☐

ABANDON* ☒

CHANGE PLANE ☐

XXX

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*

1. Back flow well. MIRU ND wellhead and NU BOP.
2. Release Otis Lockset Packer
3. Abandon Grayburg and San Andres Perforations. Set cement retainer at 3580'. Pump 75 sx of cement through retainer. Sting out and dump 25 sx on top of retainer from 3370-3580'. Displace cement and circ. hole w/drilling mud.
4. Spot a 25 sx cement plug from 210' to surface
5. Cut casing strings 3' below ground level. Erect permanent Abandonment marker.

Subject to
Like Approval
by State

RECEIVED

For further technical information contact HENRY DAVID at 397-5894.

18. I hereby certify that the foregoing is true and correct

SIGNED W.W. Baker TITLE Administrative Supervisor

DATE July 22, 1989

(This space for Federal or State office use)

APPROVED BY Shannon Shaw FOR: CHIEF, BLM, NM

CONDITIONS OF APPROVAL, IF ANY

TITLE

DATE 8-15-89

*See Instructions on Reverse Side

RECEIVED

AUG 16 1989

**OCD
HOBBS OFFICE**