

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N M Oil Co
1980
Job NM 88241

FORM APPROVED
Budget Bureau No. 1004-0135
Expires March 31, 1993

5 Lease Designation and Serial No

LC-059001

6 If Indian, Allottee or Tribe Name

7 If Unit or CA, Agreement Designation

MCA Unit

8 Well Name and No.

220

9 API Well No.

30-025-00798

10 Field and Pool, or Exploratory Area

Maljamar Grayburg/SA

11 County or Parish, State

Lea, N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1 Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2 Name of Operator

Conoco, Inc.

3 Address and Telephone No

10 Desta Drive Ste. 100W, Midland, Tx. 79705-4500 (915) 686-5424

4 Location of Well (Footage, Sec., T, R, M. or Survey Description)

660' FNL & 660' FWL
Sec. 33, T-17S, R-32E

D

12 CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Casing Integrity Test
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13 Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to perform a casing integrity test on the well in preparation for requesting temporary abandonment approval. The following procedure will be followed:

1. POOH with production equipment.
2. Set a plug within 100' of the top perf.
3. Notify the BLM 24 hours before pressure testing casing to 500 psi for 30 minutes.
4. RIH with tubing and circulate packer fluid.
5. POOH with tubing and fill hole with packer fluid.

When completed, a successful pressure test will be submitted with a reason and a request to temporarily abandon this well for another year.

RECEIVED
1997 JUL 29 AM 11:22
BUREAU OF LAND MGMT.
ROSEBELL OFFICE

14. I hereby certify that the foregoing is true and correct.

Signed

Title

Ann E. Ritchie
Regulatory Agent

Date

July 23, 1997

(This space for Federal or State office use)

(ORIG. SGD.) DAVID R. GLASS

Approved by

Title

PETROLEUM ENGINEER

Date

JUL 31 1997

Conditions of approval if any:

BLM(6)

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side