

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-01211 ✓
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-2118
7. Lease Name or Unit Agreement Name State "G"
8. Well No. 4
9. Pool name or Wildcat Saunders Permo-Penn
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4190' GR, 4203' DF

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	2. Name of Operator Charles B. Gillespie, Jr.
3. Address of Operator P.O. Box 8 Midland, TX 79702	4. Well Location Unit Letter K : 1980 Feet From The South Line and 1980 Feet From The West Line Section 3 Township 15-S Range 33-E NMMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4190' GR, 4203' DF	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Load hole with mud.
2. Cut off and pull 5 1/2" casing from approximately 4800'.
3. Spot 100' cement plug at 5 1/2" casing stub with 50' in and 50' out and tag.
4. Spot 100' cement plug across 8 5/8" shoe at 4235' and tag.
5. Cut off and pull 8 5/8" casing from approximately 1500'.
6. Spot 100' cement plug at 8 5/8" casing stub with 50' in and 50' out and tag.
7. Spot 100' cement plug across 13 3/8" shoe at 298'.
8. 15 sx cement plug at surface.
9. Weld 4" marker to surface pipe and clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE William R. Crow TITLE Exploration Manager DATE 3/17/93

TYPE OR PRINT NAME William R. Crow

TELEPHONE NO. (915) 683-1765

(This space for State Use) ORIGINAL SIGNED BY ERRY SEXTON

MAR 18 1993

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: