

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. <b>30-025-01227</b>
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-2116
7. Lease Name or Unit Agreement Name  State "F"
8. Well No. 4
9. Pool name or Wildcat Saunders Permo Penn

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Charles B. Gillespie, Jr.	
3. Address of Operator P.O. Box 8 Midland, Texas 79702	
4. Well Location Unit Letter <u>J</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>84</u> Township <u>15-S</u> Range <u>33-E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4214 DF	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

A Cibp was set and capped @ 9740' in 1990.

1. Cut off and pull 5-1/2" casing at approximately 6000'.
2. Spot 100' plug at 5-1/2" stub. 50' in and 50' out. Tag.
3. Spot 100' plug at 8-5/8" shoe @ 4230'.
4. Cut off and pull 8-5/8" CSG at approximately 1500'.
5. Spot 100' plug at 8-5/8" stub. 50' in and 50' out.
6. Spot 100' plug at 13-3/8" shoe at 296'.
7. Set 15 SX plug at surface.
8. Weld 4" marker at surface.

THE COMMISSION MUST BE NOTIFIED 24  
HOURS PRIOR TO THE BEGINNING OF  
ANY OPERATIONS FOR THE CIBP

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Kevin Widner TITLE Production Manager DATE 09/14/93  
TYPE OR PRINT NAME Kevin Widner TELEPHONE NO. (915) 683-1765

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

SEP 16 1993

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

dp