

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-9937
7. Unit Agreement Name
8. Farm or Lease Name State AC
9. Well No. 2
10. Field and Pool, or Wildcat Sanborn Frame Pool
12. County Los

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE **APPLICATION FOR PERMIT ** (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Cities Service Oil Co.
3. Address of Operator P.O. Box 69 - Hobbs, New Mexico
4. Location of Well UNIT LETTER P 4620 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 9 TOWNSHIP 15N RANGE 33E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4200 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug the above well in the following manner:

1. Load hole w/mud laden fluid.
2. Set 25 sack cement plug across Perfs. 9200-90, 9277-62, 9285-99.
3. Set 25 sacks cement plug at end point of 5 1/2" csg., half in and half out of stb.
4. If end point is above 5000', set 25 sack cement plug opposite Clarista @ 5000'.
5. Set 25 sack cement plug @ base of 8 5/8" csg. @ 4276'.
6. Set 10 sack cement surface plug w/4" nether extending 4' above ground to designate P & A location.
7. Clean location of all equipment and debris, fill pits and cellar.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED COR Robertson TITLE District Clerk DATE 3-27-65

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: