State of New Mexico als and Natural Resources Department

Form C-103 Revised 1-1-89

DISTRICT I P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION

P.O. Box 2088 Santa Fe, New Mexico 87504-2088 WELL API NO. 30-025-01245

5. Indicate Type of Lease

P.O. Drawer DD, Anesia, NM 88210	5. Indicate Type of Lease STATE XX FEE
DISTRICT III 1000 Rio Brazos Rd., Aziec, NM 87410	6. State Oil & Gas Lease No. B-9069
SUNDRY NOTICES AND REPORTS ON WELLS	
SUNDRY NOTICES AND REPORTS ON (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLU DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	JG BACK TO A 7. Lease Name or Unit Agreement Name
1. Type of Well: Off. GAS OTHER	Eidson AAO State
Office Well Well OTHER 2. Name of Operator	8. Well No.
YATES PETROLEUM CORPORATION	9. Pool name or Wildcat
3 Address of Operator	South Saunders Permo Penn
105 South Fourth Street - Artesia, NM 88210	
4. Well Location Unit Letter A: 660 Feet From The North	Line and 660 Feet From The East Line
	County
Section 31 Township 15S Range 15S Range 10. Elevation (Show whether DF, Rk	DDE MARKE
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	V/////////////////////////////////////
Check Appropriate Box to Indicate Natur	e of Notice, Report, or Other Data
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
The same of the sa	MEDIAL WORK ALTERING CASING
PERFORM REMEDIAL WORK	MMENCE DRILLING OPNS. PLUG AND ABANDONMENT
TEMPORARILY ABANDON L.	
PULL OR ALTER CASING CA	SING TEST AND CEMENT JOB
OTUED:	HER:
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed	
work) SEE RULE 1103.	
work) SEE RULE 1103. Verbal permission was obtained by Rex Gates with Yates from Paul Kautz with the Oil Conservation Commission on June 27, 1994, to plug and abandon well as follows:	
1. Set CIBP at 10350' and cap with 35' of cement on top.	
2. Set 100' cement plug across the top of the Abo at 7030 (50' above and below).	
4. Set 100' cement plug across the 5-1/2 casing stub at 5/20 (50' above and below). 5. Set 100' cement plug across the top of the Anhydrite at 1450' (50' above and below).	
6 Set a 10 sack surface plug.	
 Install regulation abandonment marker. 	- ·
NOTIFY OCD (393-6161) 24 HOURS PRIOR TO COMMENCING	PLUGGING OPERATIONS.
I hereby cerufy that the information above is true and complete to the best of my knowledge and beli	£
I hereby certify that the initiation above is a series of the series of	Production Clerk BAR
SIGNATURE /	505-748-1471 TELEPHONE NO.
TYPEOR PRINT NAME Rusty Klein	
	ORIGINAL SIGNED BY JERRY SEXTON JUL 01 1034

DISTRICT I SUPERVISOR

DATE -

APPROVED BY -