

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

JUN 12 4 00 AM '69

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No. -----
7. Unit Agreement Name -----
8. Farm or Lease Name Hulda A. Townsend
9. Well No. 10
10. Field and Pool, or Wildcat Townsend Wolfcamp
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator Humble Oil & Refining Co.
3. Address of Operator % Hobbs Pipe & Supply Co. Box 2010 Hobbs, N. M.
4. Location of Well UNIT LETTER <u>E</u> <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>9</u> TOWNSHIP <u>16-S</u> RANGE <u>35-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) Unknown

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug & abandon as follows:

1. Spot 25-sx. cement plug across perms 10,409'-10,470'.
2. Load hole with mud-laden fluid.
3. Cut & pull an estimated 3400' 5 1/2" casing.
4. Spot 25-sx. cement plug across 5 1/2" casing stub.
5. Cut & pull an estimated 1300' 8 5/8" casing.
6. Spot 25-sx. cement plug across 8 5/8" casing stub.
7. Spot 25-sx. cement plug across 11 3/4" casing shoe @ 419'.
8. Spot 10-sx surface plug with marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R M Williams TITLE Agent DATE 11 Jun 69

APPROVED BY John W. Runyan TITLE Agent DATE JUN 13 1969

CONDITIONS OF APPROVAL, IF ANY: