

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>E-605</b>

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>CITIES SERVICE OIL COMPANY</b>	8. Farm or Lease Name <b>State AP</b>
3. Address of Operator <b>P.O. Box 69, Hobbs, N.M. 88240</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>J</b> <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>16</b> TOWNSHIP <b>15S</b> RANGE <b>36E</b> NMPM.	10. Field and Pool, or Wildcat <b>Caudill Permo Penn</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>DF 3914</b>	12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon the State AP #1 in the following manner:

- (1) Pull Rods & Tubing - set 80P
- (2) Set BP @ 10260' & spot 5 sack cement on top.
- (3) Load hole w/mud laden fluid
- (4) Shoot off & pull approximately 5500' of 5 1/2" casing.
- (5) Set 30 sack cement plug 1/2 in & 1/2 out of 5 1/2" casing stub thru tubing
- (6) Set 30 sack plug 1/2 in and 1/2 out of 8 5/8" casing shoe at 4672'
- (7) Set 10 sack cement surface plug & set required marker
- (8) Clean location of all equipment, debris, fill pits & level location.

All plugs 100' in length  
mud to be 25 sacks gel/100 bbls

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____	TITLE <b>Dist. Admin. Supervisor</b>	DATE <b>2-28-72</b>
APPROVED BY _____	TITLE _____	DATE <b>MAR 2 1972</b>
CONDITIONS OF APPROVAL, IF ANY: <b>24 hr notice</b>		

Orig. Signed by  
**Joe D. Ramey**  
Dist. I, Supv.

RECEIVED

MAR 1 1972

OIL CONSERVATION COMM.  
HOBBBS, N. M.

100-100000-100000  
100-100000-100000  
100-100000-100000