

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

AUG 22 3 40 PM '69

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No. -0-
7. Unit Agreement Name -0-
8. Farm or Lease Name D. H. Crockett
9. Well No. 2
10. Field and Pool, or Wildcat Candill Permo Penn
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator Humble Oil & Refining Company
3. Address of Operator %Hobbs Pipe & Supply Co. Box 2010 Hobbs, New Mexico
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1900</u> FEET FROM THE <u>East</u> LINE, SECTION <u>21</u> TOWNSHIP <u>15-S</u> RANGE <u>36-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) Unknown

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed to plug and abandon as follows:

1. Spot 50 sack cement plug across perfs 10,363' - 10,378' and 10,597' - 10,612'.
2. Cut and pull an estimated 540' of 5½" casing.
3. Spot 50 sack cement plug across 5½" casing stub.
4. Spot 10 sack surface plug with marker.

Hole will be loaded with mud-laden fluid.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>R. M. Williams</u>	TITLE <u>Agent</u>	DATE <u></u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT V</u>	DATE <u>AUG 25 1969</u>
CONDITIONS OF APPROVAL, IF ANY:		