

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name B.C. Dickinson "B"
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201	9. Well No. 1
4. Location of Well UNIT LETTER <u>L</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>12</u> TOWNSHIP <u>15-S</u> RANGE <u>37-E</u> NMPM.	10. Field and Pool, or Wildcat Denton-Wolfcamp
15. Elevation (Show whether DF, RT, GR, etc.) 3808' DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Production from Wolfcamp perfs 9268-9414' in this well has declined to less than 1 BOPD and no remedial possibilities exist. We propose to plug & abandon as outlined below:

1. Set 7" 29# CIBP at about 9230' and cap with 2 sx cement.
2. Shoot off and pull 7" from free point (top of cement @ 6275').
3. Spot these cement plugs, leaving 9#/gal gel mud between them:
40 sx at 7" stub
40 sx across 9-5/8" shoe at 4607'
20 sx in top of well
4. Erect dry hole marker. Clear and level location and make ready for inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>A.B. Bratches</u>	TITLE <u>Dist. Drlg. Supervisor</u>	DATE <u>9/27/71</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT I</u>	DATE <u>SEP 30 1971</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

SEP 20 1971

OIL CONSERVATION COMM.
HOBBS, H. M.