

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
E-5219

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- SWD Well	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name State
3. Address of Operator P.O. Box 1978, Roswell, New Mexico 88201	9. Well No. 1
4. Location of Well UNIT LETTER D 330 FEET FROM THE North LINE AND 330 FEET FROM THE West LINE, SECTION 4 TOWNSHIP 16-S RANGE 37-E NMPM.	10. Field and Pool, or Wildcat Dean SWDS
15. Elevation (Show whether DF, RT, GR, etc.) 3840' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has been shut in since 1968 when injection pressure increased to about 2500#. This well is no longer needed in the Dean SWD System and we propose to P & A as follows:

1. Squeeze O.H. 3147-3223' w/150 sx cement.
  2. Spot 30 sk cement plug (on top of Model N packer at 3052') from 3052' to 2850'.
  3. Place 10 sx of cement (75') in top of well.
- Leave 9#/gal mud between plugs. All casing strings will remain intact. Dry hole marker will be erected and location cleared and leveled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Dist. Drlg. Supervisor DATE 9/27/71

APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT I DATE SEP 30 1971

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

SEP 20 1971

OIL CONSERVATION COMM.  
HOBBBS, H. C.