

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

5. Lease Designation and Serial No.  
LC 029405A

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation  
MCA Unit

8. Well Name and No.  
49

9. API Well No.  
30-025-08056

10. Field and Pool, or Exploratory Area  
Hajjamar Grayburg/SA

11. County or Parish, State  
Lea, NM

**SUBMIT IN TRIPLICATE**

1. Type of Well  
 Oil Well     Gas Well     Other

2. Name of Operator  
Conoco, Inc.

3. Address and Telephone No.  
10 West Dr., Ste 100W, Midland, TX 79705    (915) 686-6548

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  
1980 FNL & 1980 FEL  
Sec. 20, T-17S, R-32E

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

It is proposed to plug and abandon this well according to the following procedure and the attached wellbore diagrams:

- Spot 10 sxs cement on top of RBP @ 3501'.
- Circulate hole with brine gel mud.
- Spot 20 sxs cement 1930'-2050'.
- Spot 20 sxs cement 880'-1000'.
- Spot 20 sxs surface plug. Fill 12 1/2" casing from top.
- Install dry hole marker and clean location.

RECEIVED  
 FEB 22 11 33 AM '96  
 OADR  
 ADR

14. I hereby certify that the foregoing is true and correct

Signed Jonny Hoover Title Sr. Conservation Coordinator Date 2/21/96

(This space for Federal or State office use)

Approved by (ORIG. SCD.) JOE G. LARA Title PETROLEUM ENGINEER Date 4/1/96

Conditions of approval, if any: See attached. Also for plug @ step #4 perf. & squeeze cement outside 7" csg.

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.