

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

COMMISSION  
1980  
MEXICO 00240  
FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other

Injection

2. Name of Operator

Conoco, Inc.

3. Address and Telephone No.

10 Desta Dr. Ste 100W, Midland, TX 79705

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

2615' FSL & 25' FWL  
Sec. 20, T-17S, R-32E

5. Lease Designation and Serial No.

LC 029405B

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

MCA Unit #61

9. API Well No.

30-025-12771

10. Field and Pool, or Exploratory Area

Maljamar Grayburg/SA

11. County or Parish, State

Lea

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☒ Other Casing Integrity Test

- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

It is proposed to perform the following operations in order to prepare this well for temporary abandonment:

1. Set plug in profile nipple below on/off tool.
2. Bleed pressure off of injection tubing to test plug.
3. Get off on/off tool and POOH with injection tubing.
4. Top off casing with packer fluid.
5. Install pressure recorder and perform casing integrity test for 30 minutes @ 500 psi.  
Notify BLM/NMOCD 24 hrs prior to test.

14. I hereby certify that the foregoing is true and correct

Signed

*Joe G. Lara*

Title

Sr. Conservation Coordinator

Date

12/19/94

(This space for Federal or State office use)

(ORIG. SGD.) JOE G. LARA

Title

PETROLEUM ENGINEER

Date

1/12/95

Approved by  
Conditions of approval, if any:

**RECEIVED**

JAN 17 1993

UDD HOBBS  
OFFICE