

Form 5-331
(May 1963)

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Form Approved
Project 10-100, 10-101, 10-102

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

LC-029509(2)

6. DESIGN, ALLOTTEE OF TRACT NAME

7. UNIT AGREEMENT NAME

8. TERM OF LEASE NAME

BAISH A

9. WELL NO.

9

10. FIELD AND POOL, OR WILDCAT

BAISH-VATES

11. SEC., T., R., S., OR LBL AND
ELEVATION OR AREA

SEC 21, T-17S, R-32E

12. COUNTY OR PARISH 13. STATE

LEA N.MEX.

1. OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

Continental Oil Company

3. ADDRESS OF OPERATOR

P. O. Box 460, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 11 below.)

At surface

1650' FNL & 1650' FEL, SEC 21

14. PERMIT NO.

15. FINANCIALS (Show whether DE, BY, OR, etc.)

4045' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

FULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and record feet sent to this work.)

It is proposed to plug and abandon this well by the following procedures.

Spot a 25 sack plug from TD to cover perforations from 2381' to 2344'. Fill well with 10# mud. Spot a 10 sack plug at surface and cap with dry hole marker. Clear location for inspection.

ADDITIONAL: In addition to above, cut and pull 4 1/2" casing from free point and place 25-sack cement plugs at 800-900 feet and 200-300 feet. If 4 1/2" casing cannot be pulled from below 300 feet, place 100 foot plug inside pipe at 800-900 feet.

18. I hereby certify that the foregoing is true and correct

SIGNED

M. E. G. [Signature]

TITLE Adm. Section Chief

DATE 6-25-70

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED
AS AMENDED
AUG 10 1970

DATE

USGS-5

FILE

*See Instructions on Reverse Side

ARTHUR R. [Signature]
DISTRICT ENGINEER