

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

HOBBBS OFFICE O. C. C.  
NEW MEXICO OIL CONSERVATION COMMISSION

3-OCC  
1-File

APR 14 3 25 PM '66

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>

5. State Oil & Gas Lease No.

E-10070

### SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Dry</b>		7. Unit Agreement Name
2. Name of Operator <b>Tidewater Oil Company</b>		8. Farm or Lease Name <b>State AU</b>
3. Address of Operator <b>Box 249, Hobbs, New Mexico</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>E</b> , <b>1980</b> FEET FROM THE <b>North</b> LINE AND <b>1300</b> FEET FROM THE <b>West</b> LINE, SECTION <b>19</b> TOWNSHIP <b>16S</b> RANGE <b>37E</b> NMPM.		10. Field and Pool, or Wildcat <b>Wildcat</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3849.4 GR</b>		12. County <b>Lea</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

No shows of oil or gas were encountered.

We propose to plug and abandon well as follows: Lay 110 sx. cement plug from TD back above 6270'. Lay 25 sx. plug in top San Andres at 4860'. Lay 25 sx. plug in top of Yates at 3210'. Lay 25 sx. plug in bottom of 8-5/8" casing. Lay 10 sx. plug in top of 8-5/8" casing. Install 4" OD dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed By:  
**B. M. BREINING**

SIGNED \_\_\_\_\_ TITLE **Area Engineer** DATE **4-13-66**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

