

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION C. C.

MAY 15 10 38 AM '69

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name State CK
9. Well No. 1
10. Field and Pool, or Wildcat Lovington, East
12. County Lee

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
2. Name of Operator Cities Service Oil Company
3. Address of Operator P. O. Box 69 - Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER <u>G</u> <u>2040</u> FEET FROM THE <u>North</u> LINE AND <u>1930</u> FEET FROM THE <u>East</u> LINE, SECTION <u>19</u> TOWNSHIP <u>16S</u> RANGE <u>37E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3848 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**TD 11400 Strawn - It is proposed to Plug and Abandon this well in the following manner:**

1. Displace hole w/8.9# per gal. drilling mud.
2. Displace 25 sx plug 11400-308; 25 sx 10303-211, 25 sx 9706-9614, 25 sx 8328-8236, 25 sx 6354-6262.
3. Set 25 sx plug 1/2 in and 1/2 out 8 5/8 casing 4319.
4. Set 10 sx plug in top from 30' to surface and set 4' pipe dry hole marker.
5. Clean location of all equipment and debris, fill pits and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE District Office Manager DATE May 14, 1969

APPROVED BY [Signature] TITLE [Signature] DATE [Signature]

CONDITIONS OF APPROVAL, IF ANY: