

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT - A (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Tipperary Land & Exploration Corp.		8. Farm or Lease Name Allen
3. Address of Operator 500 West Illinois; Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER <u>F</u> <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>1650</u> FEET FROM THE <u>West</u> LINE, SECTION <u>1</u> TOWNSHIP <u>15S</u> RANGE <u>36E</u> NMFM.		10. Field and Pool, or Wildcat Wildcat
11. Elevation (Show whether DF, RT, GR, etc.) 3874 GR		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Load hole with mud laden fluid
2. Set 15 sx plug at 10,500 and pull tubing
3. Cut off and pull 4 1/2" casing estimated 9000'.
4. Set 25 sx cement plugs at: 8250' Abo; 6350' Glorieta; 4850' Base of 8 5/8" casing
5. Attempt to pull 8 5/8" casing
6. 25 sx plug at 400' Base of 13 3/8" casing and 10 sx at surface
7. Install permanent marker

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. W. Keener R. W. Keener TITLE Engineer DATE 8/13/71

APPROVED BY [Signature] TITLE SURVEY DISTRICT DATE AUG 15 1971

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

1967

OIL
NATIONAL COMM.
FEB. 11, 1