

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

30. Indicate Type of Lease
State Fee
31. State Oil & Gas Lease No.
B-9970

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL GAS WELL OTHER: P&A

2. Name of Operator
MESA PETROLEUM CO.

3. Address of Operator
PO BOX 2009/AMARILLO, TEXAS 79189-2009

4. Location of Well
UNIT LETTER I 1980 FEET FROM THE SOUTH LINE AND 660 FEET FROM
EAST THE LINE, SECTION 14 TOWNSHIP 16S RANGE 35E RUPM.

5. Elevation (Show whether DF, RT, GR, etc.)
3970' GR

6. Unit Agreement Name

7. Name of Lease Name
SKELLY STATE COM

8. Well No.
1

9. Field and Pool, or Wildcat
SHOEBAR WC NORTH

10. County
LEA

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to P&A well as follows:

- Set CIBP @ 9550' plus 50' cement.
- Cut off 5 1/2" csa at free point (6200')
- Load hole with 9.5 ppc mud and set 100' plug; 50' in & out of csa stub.
- Tan plug. Repeat if needed.
- Set 100' plug; 50' in and out of 9 5/8" csa shoe set @ 4805'.
- Tan plug.
- Set 100' plug across top of salt at 3100'.
- Perf 9 5/8" csa @ 450' and squeeze with 100' cement in & out of csa (13 3/8" csa set at 430').
- Set 100' plug to surface.
- Install Dry Hole Marker.

XC: NMCCD-H(0+2), GEN RCDS, ACCTG, PROD ENG, DRLG, WELL FILE, MIDLAND, HOBBS, PARTNERS

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

DATED R. S. Mark TITLE REGULATORY AGENT DATE 1-3-85

ORIGINAL SIGNED BY JERRY GERTON
APPROVED BY DISTRICT SUPERVISOR TITLE _____ DATE JAN - 7 1985

CONDITIONS OF APPROVAL, IF ANY: