

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFF CE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No.

K-4619

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator K. K. Amini	8. Farm or Lease Name Pennzoil "33" State
3. Address of Operator P. O. Drawer 3068, Midland, Texas 79701	9. Well No. 1-Y
4. Location of Well UNIT LETTER 0, 660 FEET FROM THE South LINE AND 2020 FEET FROM THE East LINE, SECTION 33 TOWNSHIP 16-S RANGE 34-E NMPM.	10. Field and Pool, or Wildcat Vacuum Gray-S.A.
15. Elevation (Show whether DF, RT, GR, etc.) 4079.8 GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### To Plug & Abandon Upon Approval -

- #1 - Pull rods & tubing.
- #2 - Set C.I.B.P. @ 4625'.
- #3 - Dump 35' of cement on plug.
- #4 - Load hole with 9.5# laden fluid.
- #5 - Cut off 4 1/2" casing @ approx. 4000'.
- #6 - Pull 4 1/2" casing.
- #7 - Run 2 3/8" tubing.
- #8 - Set cement plug, 35 sks. in and out of cut off.
- #9 - Set cement plug, 40 sks. in and out @ base of 8 5/8" csg. @ 401'.
- #10 - Set 10 sks. plug in top of 8 5/8" csg. with marker.
- #11 - Clean up location.

\* 100' CEMENT PLUGS AT BASE OF SALT & TOP OF THE SALT IS REQUIRED

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Comptroller DATE 12/3/75

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: