

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-7

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG SALT TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT - C-1031 FOR SUCH PROPOSALS.

34. Indicate Type of Lease
State ☒ Fee ☐
3. State Oil & Gas Lease No.
B-11078 & E-4199

1. ☐ OIL WELL ☒ GAS WELL ☐ OTHER	7. Unit Agreement Name
2. Name of Operator Amoco Production Company	8. Farm or Lease Name State MM Com
3. Address of Operator P. O. Box 68, Hobbs, New Mexico 88240	9. Unit No. 1
4. Location of well UNIT LETTER <u>I</u> <u>3637</u> FEET FROM THE <u>North</u> LINE AND <u>810</u> FEET FROM THE <u>East</u> LINE, SECTION <u>3</u> TOWNSHIP <u>16-S</u> RANGE <u>32-E</u> NMPM.	10. Field and Pool or Visual North Anderson Ranch Wolfcamp
11. Elevation (Show whether DF, RT, CR, etc.) 4831.8' RDB	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☒
COMMENCE DRILLING OPS. ☐
CASING TEST AND CEMENT JOBS ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

OTHER ☐

17. Describe Progress or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to acidize the Wolfcamp as follows:

Move in service unit and kill well. Pull rods and pump. Unseat anchor and lower tubing, and anchor to 8000±. Run 1-1/4" pump with E.L. rods. Return to production. If the well pump off proceed with next step. Pull rods and pump. Unseat anchor and pull tubing and anchor. Run in hole with tubing and packer. Set packer at 9700±. Acidize Wolfcamp perms 9812'-18' as follows:

- a) Pump 3000 gals 15% NEFE HCL acid with additives approx. 3 BPM.
- b) Flush with 50 bbls of brine water.

Swab well for one day. Release packer and pull out of hole. Run in hole with 1 joint tubing, tubing anchor and tubing with standard sand on bottom. Run pump with rod string design for pump set at 6000'. Place well back on production.

0+4-NMOCD,H 1-HOU R. E. Ogden RM 21.150 1-F. J. Nash, HOU RM 4.206 1-SUSP 1-PJS

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Peter J. Seana
ORIGINAL SIGNED BY EDDIE SEAY

TITLE Assist. Admin. Analyst

DATE 7-19-83

OIL & GAS INSPECTOR

JUL 20 1983

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE